
Title: Auma SQ (AC) ¼-Turn Electric Actuators fitting to i-RSVP
Reason for use: Information
Document Owner: Bill Burrows

Proc. No.	PAGE NO	ISSUE NO	ORIGINAL ISSUE DATE	CURRENT ISSUE DATE
WSMS002b	1 of 4	1	02/03/17	02/03/17

- The Auma Part-Turn range is rated to 60C maximum thus DES Ltd supply a mounting kit in order to protect the actuator from any conducted or radiated heat that the valve can give out when under temperature. However this does not mean that when lagging the valve after installation, it can be lagged right up to the actuator. This will create a heat spike which will eventually ‘cook’ the electrics and thus hinder its operation and efficiency leading to the eventual breakdown.
- The common causes of valve failure usually compromises of four faults: incorrect setting of actuator mechanical stops & electrical limits; or valve stem being driven into valve; or ball being reversed so that unlapped side of ball paired with lapped seat.
- DES Ltd is providing this report as a guide to handling the valve and actuator packages when installing and commissioning them on site.
- Please note: **Clockwise to close; Counter Clockwise to open.** Mogas Ball Valves have a 96° travel, allowing an extra 3° of travel either side of open or closed. This is to allow thermal expansion of the stem under temperature.

Actuator Installation:

- Ideally the valve actuator packages supplied by DES Ltd will be Factory Acceptance Tested at the DES Ltd workshop, and thus will have the appropriate Mechanical and Electrical limits set.
- When the DES Ltd actuators are removed for welding & PWHT, please mark the bracket and actuator so that when the actuator is re-installed, if the marks line up, no electrical or mechanical limit adjustment is required. The only point that **Mogas** and **DES Ltd** stress when welding is to leave the valve open. This will allow the free movement of air/heat in the line otherwise the ball in the closed position will act as a barrier and allow the heat to build up around the ball and hence conduct through the stem. Further to this, do not insulate or wrap the thermocouples around the entire valve.
- Where ever possible, try and fit site supplied actuators to the valves in workshop as opposed to in line. It is easier to check to see if the valve is fully open (smooth bore) or fully closed.

Workshop/In line Installation:

1. Set valve to fully open position. This is your reference point to establish the fully open stop.

Proc. No.	PAGE NO	ISSUE NO	ORIGINAL ISSUE DATE	CURRENT ISSUE DATE
WSMS002b	2 of 4	1	02/03/17	02/03/17

Attach Mounting Bracket (adaptor plate) and Stem Adaptor (stem coupling). Please do not tighten bolts as you may need the initial play later to help line up the bolt holes for the actuator/gearbox.

2. Before attaching actuator, please ensure that the actuator is fully open (rotate counter clockwise fully).
3. Attach the actuator to the mounting bracket ensuring that a slide fit has occurred between the male insert of adaptor (coupling) and the female connection of the gearbox/actuator drive bush. If you cannot achieve a slide fit, **DO NOT FORCE THE ACTUATOR** on to the coupling. This will potentially cause the stem to be pushed in and thus rolling the ball off the seat (guaranteed leakage). Please use emery cloth or any other means necessary to ensure a slide fit.
4. Once the actuator has been successfully placed on to the valve, this is where all the nuts & bolts need to be tightened. Please note that all fittings should come with Norlock or other type of shake-proof washers, if not please inform DES Ltd or supply own. This helps to secure actuator to the valve, especially under any continuous vibration which may cause the actuator to shake loose.
5. When adjusting the closed/open stops on the Auma SQ, there are two Cap Head Screws located within two M20 screwed covers below the handwheel. The left hand stop will allow you to adjust the open position of the valve. The right hand stop adjusts the closed position.
6. Setting the open stop on the Auma SQ, the valve should be fully open, and the manufacturer's machined profile on the supplied stem adaptor is touching the Mechanical Position Stop (MPS) on the valve mounting pad (please see p8 of the Mogas IOM manual also).



Machined Profile of the Stem Adaptor and the Mechanical Position Stop (MPS)

If the ball of the valve has encroached into the flow path (look up the bore of valve if in workshop) unwind the Auma SQ until full bore (and adaptor makes contact with stop) and then set stops. At this point, the SQ mechanical stop should be wound in until **just** touching the actuator quadrant.

7. Setting the close stop on the actuator, the valve should be wound fully closed (clockwise) until the manufacturer's machined profile on the supplied stem adaptor is touching the 'fixed stop' on the valve mounting pad. At this point, the actuator stop should be wound in until just touching the actuator quadrant.
8. It is recommended that the Auma SQ Part-turn actuators should be set to work on electrical limits rather torque. The selector switch on the local control needs to be set to '0' before the limits & torques can be adjusted. In the menu display, scroll through the 'settings' options until you find Seating Mode.

Proc. No.	PAGE NO	ISSUE NO	ORIGINAL ISSUE DATE	CURRENT ISSUE DATE
WSMS002b	3 of 4	1	02/03/17	02/03/17

Enter edit mode on the Display and enter default password of '0000' to access and change. Then set both the open and closed positions to Limit rather than Torque.

- Then the Limit switches themselves need to be set to suit the valve. In the menu display, scroll through the 'settings' options until you find 'Set Limit Switches' and enter default password of '0000' to access and change. Enter edit mode on the Display and if you are setting up from the closed position (assuming the valve is in the closed position from point 8) choose the Closed Position option. Double check to insure that the valve is at the mechanical stop (resistance is starting to build on the handwheel when rotating clockwise) but do not over force the stop.

DES Ltd recommend rotating the Auma Handwheel counter clockwise by ½ a turn (no more) so that the Auma is backed off the 'closed' mechanical stop. Accept the new end position setting at this point for the Closed Limit. The LED's and display should indicate that the new end position has been accepted.

- Then the 'Open' limit needs to be set. Enter edit mode on the Display and choose Open Position. Then engage manual operation and wind the valve fully Open until it hits the gearbox mechanical stops and the mechanical position stop (MPS) on the valve. Then wind the handwheel in the opposite direction by ½ turn. Accept the new end position setting at this point for the Closed Limit. The LED's and display should indicate that the new end position has been accepted.
- Then the torque setting needs to be set next. Even though the actuator is set to go out on limits, the torques are set so that the actuator does not exceed the mast limitation. In the menu display, scroll through the 'settings' options until you find 'Torque' and enter edit mode on the Display. Then enter default password of '0000' to access and change. The Maximum Torque Figures as per the differential pressure across each type of RSVP is as follows:

RSVP Model	Differential Pressure	Auma Part-Turn Model Max Torques	SQ Torque Setting
RSVP-UC 1500#	Up to 200 Barg DP	SQ05 = 150Nm	88Nm max
RSVP-UF 1500#	Up to 200 Barg DP	SQ07 = 300Nm	270Nm Max
RSVP-UL 1500#	Up to 70 Barg DP	SQ07 = 300Nm	300Nm max
	70 Barg - 135 Barg DP	SQ10 = 600Nm	600Nm Max
RSVP-UM 1500#	Up to 200 Barg DP	SQ12 = 1200Nm*	700Nm max
RSVP-UC 3100#	Up to 170 Barg DP	SQ07 = 300Nm	179Nm max
RSVP-UF 3100#	Up to 170 Barg DP	SQ10 = 600Nm	330Nm max
RSVP-UL 3100#	Up to 170 Barg DP	SQ10 = 600Nm	560Nm max
RSVP-UM 3100#	TBC		

**If 22s Motor Speed option selected, for 16s Motor Speed option, the maximum torque available reduces to 900Nm, actual torque setting for the RSVP does not change.*

- When electrically cycling the valve open and closed, it would do well to check the actual valve stops as well to double check that there is no significant under-travel. So when cycling the valve open and closed electrically, ensure that the gap between the machined profile and the cap head screw is no larger than 0.5mm or else the valve will be off its 'sweet spot' when it hits the closed limit and will not be tight shut-off. Also if the same gap appears on the opening stroke, if the gap is bigger than 0.5mm, then the seat ring is exposed to the flow. If this gap is bigger than 0.5mm, return to step 7 or 8 and instead of backing of ½ a turn, back off only 1/3 of a turn instead. DES Ltd does not believe this will be required and this can easily be rectified when DES Ltd visits site to commission the valves.
- Conversely if the valve torques out, i.e. a torque fault is registered on the display, return to step 5 and/or 6 and instead of backing of ½ turn, back off ¾ turn instead.

Proc. No.	PAGE NO	ISSUE NO	ORIGINAL ISSUE DATE	CURRENT ISSUE DATE
WSMS002b	4 of 4	1	02/03/17	02/03/17

Please note: There is an allowance for a 5% Over/Under Travel in the Mogas design. However the above ensures that you are well within tolerance.